



Flange diagram according to ISO 9409-1-63-4-M6




Interference contour from machine body

Maximum interference contour




Tool Center Point
TCP (on the plane of the flange)

TCP - working range






Z (1:1)




Connecting dimensions, valid for article number A_00035-02-HND

m= kg	A	p= bar
proj. storage surface = m²	P= kW	\dot{V} = l/min
First angle projection	U= V / Hz / Ph	
	Imax= A	

12 11 10 9 8 7 6 5 4 3 2 1

-  All fastening holes $\varnothing 17,5\text{mm}$ for screws M16 (DIN ISO 4014/4017 -8.8) without washer. Fastening holes are coloured red.
-  Fastening holes filled blue are difficult to access. We recommend using fastening holes coloured red.
-  Drilling holes for locating pins are filled red. Recommended dimensions of locating pins: $\varnothing 12\text{ h6 } \left(\begin{smallmatrix} 12 \\ 11,989 \end{smallmatrix} \right)$



12 11 10 9 8 7 6 5 4 3 2 1